

Model Number

■ Air source handling assembly

① Pressure regulator filter + oil mist FC Series



FC 200 - 08 - M -

① ② ③ ④

① Series	② Nozzle diameter			③ Drainage mode		④ Pressure Gauge	
FC200	06	PS 1/8"	FC200	blank	Semi-Auto drain	blank	pressure gauge
FC400	08	PS 1/4"	FC200, FC400	M	Manual drain	N	no pressure gauge
FC600	10	PS 3/8"	FC400	AD	Auto Drain		
	15	PS 1/2"	FC400				
	20	PS 3/4"	FC600				
	25	PS 1"	FC600				

② Air filter + pressure regulator + oil mist F+R+L Series



F 200 + R 200 + L 200 - 08 - M -

① ② ③ ④

①Series	② Nozzle diameter			③Drainage mode		④Pressure Gauge	
200	06	PS 1/8"	200	blank	Semi-Auto drain	blank	pressure gauge
400	08	PS 1/4"	200, 400	M	Manual drain	N	no pressure gauge
600	10	PS 3/8"	400	AD	Auto Drain		
	15	PS 1/2"	400				
	20	PS 3/4"	600				
	25	PS 1"	600				

③ Air filter + pressure regulator F+F+R Series



F 200 + F 200 + R 200 - 08 - M -

① ② ③ ④

①Series	② Nozzle diameter			③Drainage mode		④Pressure Gauge	
200	06	PS 1/8"	200	blank	Semi-Auto drain	blank	pressure gauge
400	08	PS 1/4"	200, 400	M	Manual drain	N	no pressure gauge
600	10	PS 3/8"	400	AD	Auto Drain		
	15	PS 1/2"	400				
	20	PS 3/4"	600				
	25	PS 1"	600				